



QUICK START GUIDE

CLASSIC 140




NILFISK




A




1




2



3




4




A




5




6



7




8




A




9




10



11




12




A




13



14






15





A



16




17




A




18



19




20




B




1




2



3




4




B




5



6




7




B




8




9



10




11




B



12



13



GENTLE NOZZLE




ROUGH NOZZLE



HARD SURFACES ONLY

14





15



C




1




2



3




C




4


4.1




4.2



5




MAX 2min



6


6.1




6.2



6.3



6.4





7







D



>5min




E






5


5.1



5.2




6




7

7.1



7.2



8




F




1


1.1



1.2




2




3


3.1



3.2





4








5



6



FR
Cet appareil
se recycle

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



OU

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !